IQ DOORBELL ADAPTER QUICK INSTALL GUIDE

Qolsys
QUALITY OF LIFE

OVERVIEW

The IQ Doorbell Adapter is a great add-on device for automating simple actions. For example, taking a video or turning on a light when someone presses your doorbell, and sending you a text message or email alert!   The IQ Doorbell Adapter wires effortlessly into an existing door bell using the included pre striped leads.

WIRING DIAGRAM

SPECIFICATIONS

Sensor: 3.25''''H x 1.3''W x 1''D

Wireless signal range: 600ft (200M), open air.
Code outputs: tamper, tamper restore, alarm, alarm restore, low battery.
Transmitter frequency: 319.5 MHz
Unique code ID
Supervisory keep-alive interval: 70 minutes.
RF Peak field strength: typical 36000 uV/m at 3m

Operating Temperature: -10C~50C
Relative Humidity: 5-95% Non-Condensing
Storage Temperature: -40-80C

Replace battery with exact replacement every 5 years with 3V Lithium (x2).

(2)   -Panasonic CR2032
        -Energizer CR2032
        -Duracell DL2032

This is a quick guide for experienced installers only. For a detailed installation manual refer to the documentation found on the "Documentation" tab on http://dealers.qolsys.com (login required, request access at PortalAccess@Qolsys.com)

| STEP 1 | INSERT DOORBELL ADAPTER INTO SENSOR TERMINALS | STEP 2 | TIGHTEN TERMINAL SCREWS | STEP 3 | WIRE ADAPTER LEADS TO DOOR BELL CHIME |

TRANS

FRONT

The Adapter leads wire to the doorbell chime's TRANS and FRONT terminals inside the house.

Simply wire them inline with the existing doorbell button wires.

STEP 3 LEARN INTO PANEL

Touch "Settings"

Touch "Installation"

Touch "Security Sensors"

Touch "AutoLearn Sensor"

Tamper sensor by opening cover until you hear the panel chime

Add

Select "Doorbell" as your sensor type and customize settings as desired, then touch Add

Test sensor to ensure proper function

GOT QUESTIONS?
CONTACT TECH SUPPORT
TechSupport@Qolsys.com