IQ TEMP QUICK INSTALL GUIDE

STEP 1 | CHOOSE INSTALLATION LOCATION

SPECIFICATIONS

The IQ Temp is designed to alert you if temperatures drop below 40°F or rise above 100°F. This early warning may help you protect your valuables, pets and home from extreme heat or cold in the event of a HVAC or thermostat failure.

Mounting Locations
Ideally suited for a wide range of applications including:

- Bathrooms
- Laundry Rooms
- Basements

NOTE: Avoid areas that may retain heat, such as furnace rooms or near hot water pipes

SEE REVERSE FOR REMAINING STEPS

Features:

Low Temp and High Temp Warning
- Low Temp alarm: Temperature drops below 40F, restores when temperatures rises above 45F
- High Temp alarm: Temperature rises above 100F, restores when temperature drops below 95F

Sensor:
- Cover tamper
- Unique ID for each function
- Temperature check every 5 minutes
- Battery checked every hour

Batteries:

(2) - Panasonic CR2032
     - Energizer CR2032
     - Duracell DL2032

STEP 2	REMOVE BATTERY TABS	STEP 3	APPLY ADHESIVE	STEP 4	INSTALL IN DESIRED LOCATION	STEP 5	LEARN INTO PANEL

STEP 5 — LEARN INTO PANEL

Touch "Settings" • Touch "Installation" • Touch "Security Sensors" • Touch "AutoLearn Sensor"

STEP 6A — LEARN AS LOW TEMP (40°F)

Tamper sensor by opening the case until you hear the panel chime

STEP 6B — LEARN AS HIGH TEMP (100°F)

Remove both of the batteries

Hold the tamper button while you insert the batteries

Select "Freeze" as your sensor type and customize settings as desired

Sensor Type	Freeze
Sensor Name	Freeze Sensor
Chime Type	High Wire
Sensor Group	52-Freeze
Voice Prompts	On

Add

Click "Add"

*NOTE: Sensor Type "Freeze" (Sensor Group 52) is used for both Low Temp sensors and High Temp sensors. You can customize the Sensor Name to differentiate which one you are learning

GOT QUESTIONS?
CONTACT TECH SUPPORT
TechSupport@Qolsys.com